

## RS-232C Communication Protocol for IIZWP32-H01

DVB-T Models Suits 32”H ONLY– for all other models see next protocol

<b>Communication Parameters</b>	
Baud rate	9600 bps
Data length	8 bits
Parity	None
Stop bit	1 bit
Communication code	ASCII code
<b>Flow Control</b>	<b>None</b>

<b>RS232 CODES</b>		<b>RS 232 FUNCTION</b>
CHNL	00~99	Channel Number
MUTE	99	Toggle On / Off
MUTE	00	Mute On
	01	Mute Off
PWRX	99	Toggle On / Off
POWR	01	Power On
	00	Power Off
SRCE	00	Source OSD window
ITVA	00~99	INPUT TV Analog
IDVB	00	INPUT TV Digital
ISCT	01~02	INPUT Scart 1~2
ICMP	00	INPUT Composite Video
ISVD	00	INPUT S-Video
IRGB	01	INPUT Component
IHDM	01~02	INPUT HDMI 1~3
IAPC	00	INPUT PC Analog RGB
UPXX	00	Increase channel by 1 and other functions
DOWN	00	Decrease channel by 1 and other functions
LEFT	00	Increase volume by 1 and other functions
RGHT	00	Decrease volume by 1 and other functions
ENTR	00	Select menu item
SLCT	00	Select menu item
MENU	00	Menu
EXIT	00	Exit
INFO	00	Information
DUAL	01	Change Sound Format
VOLM	25	Volume Level 25
	50	Volume Level 50
	75	Volume Level 75

## Command Syntax

Command + Number ex) CHNL90, POWR01

\*\*\* No space between command and number \*\*\*